


## AXIAL FANS FOR ATEX EXPLOSIVE ATMOSPHERES

- ATEX certified fans for Zone 2 (gas) and Zone 22 (dust)
- Fans are in compliance with ATEX Equipment Directive 94/9/EC
- ATEX certified fans for Equipment Category 3 (see back for zone and category descriptions)

## MECHANICAL FEATURES





## ATEX ATMOSPHERE DESCRIPTION

The table below defines the zones and indicates what category ATEX Certificate is required for equipment in those zones.

Zone		ATEX Equipment	Broad Definitions of Zones	
Gases & Vapors	Dust	Category	(for guidance only)	Level of Protection
0	20	1	Explosive atmospheres are present continuously, for long periods or frequently	Very High
1	21	2	Explosive atmospheres are likely to occur under normal operation, occasionally	High
2	22	3	Explosive atmospheres may occur under abnormal operation and persist for a short period only	Normal

## **Motor Requirements for ATEX Atmospheres**

Zone 0, 20	Electric motors cannot be used
Zone 1	Flameproof motors
Zone 21	Dust ignition proof motors
Zone 2	Non-sparking motors
Zone 22	Dust ignition proof motors

The end-user is required to evaluate the environment where equipment is to be located and operated. When evaluating hazardous locations, it is important to consider the hazardous material (gases or dusts) itself, how the material may interact with the surroundings (atmosphere, equipment and personnel), likelihood of explosion due to the surroundings, and the level of any anticipated effects.

The close evaluation of the hazards will allow the end-user to provide Aerovent with a specification for equipment located in the hazardous location. To assist the end-user or their representative, Aerovent offers an ATEX Customer Inquiry Form as a guide to provide all essential information to ensure the correct category and zone are selected for each fan. The form can be provided by your Aerovent representative or downloaded from Aerovent's website at http://www.aerovent.com/industries-and-applications/hazardous-locations-(atex).